

Motorcycle/Car/ATV Computer CA-080-XXX User Manual

Thanks for purchasing the ATV/Motorcycle/scooter/vehicle computer; this manual is specifically designed for CA080-XXX-XX series. CA080-06X/10X/12X/16X/21X/22X/26X series has needle speedometer scale, weather CA080-3XX/4XX/5XX/6XX/7XX series has different needle tachometer scales, each series has different models, each model has different LED indicators. You may find that the photo has a set of LED indicators different from your computer, the photo is for reference only.


Different series with different needle tachometer or speedometer scales are as bellows:

CA080-06X: 60MPH
CA080-10X: 100MPH
CA080-12X: 120MPH
CA080-16X: 160km/h
CA080-21X: 210km/h
CA080-22X: 220km/h
CA080-26X: 260km/h

CA080-3XX 6,000rpm
CA080-4XX 9,000rpm
CA080-5XX 12,000rpm
CA080-6XX 15,000rpm
CA080-7XX 20,000rpm

The last suffix “-XX can be identified up case material of bezel as bellows:
No. suffix: Plastic material.

-AB: Black anodized Aluminum upper ring & sleeve
-CP: Chrome plated Aluminum upper ring & sleeve
-C: Chromed plastic upper ring
-B: Black plastic upper ring



PANEL DESCRIPTIONS

1. Tachometer or Speedometer Scale
2. Needle Tachometer /speedometer
3. 1st row: Current Speedometer
4. 2nd row: Other functions
5. Gear Indicator
6. RESET Button
7. MODE Button
8. Bar Fuel or Temperature gauge
9. 5 LED indicators

Model No	LED Indicators				
CA-080-XX0					
CA-080-XX1					
CA-080-XX2					
CA-080-XX3					
CA-080-XX4					
CA-080-XX5					
CA-080-XX6					
CA-080-XX7					
CA-080-XX8					
CA-080-XX9					

FEATURES

- Needle tachometer or speedometer, integrated digital functions and 5 LED indicators for different models.
- LCD displays needle speedometer, bar fuel gauges, gear indicator and one other function simultaneously.
- Backlight brightness can be manual adjust from 0, 1, 2...9 for different brightness.
- Gear indicator which calculates gear by comparing speed and RPM.
- Fuel gauge full and empty resistances are fully adjustable and it can connect to sender units with resistance range up to 990 ohms. In reserve mode, the fuel gauge is not displayed and fuel symbol lights when the input wire is connected to -ve. The gauge can be switched off entirely if not required.
- Flexible battery warning voltage setting from 11.0 to 15.0V. Highly visible 3 shift warning LED indicator.
- Allows end user to adjust odometer when the odometer is less than 30km / 18.6 miles
- Universal wheel circumference setting range from 1 to 3999mm.
- Includes bracket, RPM sensing wire, hall or reed speed sensor, fitting kits, wiring harness, main unit sleeve and temperature sensor.
- Excellent water resistant, anti vibration structure and noise immunity design.

SPECIFICATIONS


Functions	Symbol	Specifications
Needle Speedometer		CA-080-06X 60MPH CA-080-10X 100MPH CA-080-12X 120MPH CA-080-16X 160km/h CA-080-21X 210Km/h CA-080-22X 220Km/h CA-080-26X 260Km/h
Needle Tachometer		CA-080-3XX 6,000rpm CA-080-4XX 9,000rpm CA-080-5XX 12,000rpm CA-080-6XX 15,000rpm CA-080-7XX 20,000rpm
Digital Tachometer	rpm	100~19,999 rpm
Speedometer	Km/h / MPH	2-399 km/h (248 MPH)
Maximum speed	MAX SPD	2-399 km/h (248 MPH)
Average speed	AVG SPD	2-399 km/h (248 MPH)
Temperature Meter	°C/°F	0°C-180°C / 32°F -356°F, HI or oFF <0°C display -L-, >180°C display -H-
Max. Temperature	MAX °C/°F	0°C~180°C / 32°F ~356°F
Trip meter 1or2	TRIP 1 or 2	0.0~999.99 km/624.9Miles
Trip meter 3	TRIP 12	999.99-0 km/Miles count down
Odometer	ODO	0 - 999999 km, 0-624999 Miles
12/24 Hour Clock		AM/PM 0:00' ~ 11H59' / 23H59'
Riding timer	RT	0 ~ 99H59'59"
Total Riding Time	TT	0 ~ 999999H
Hour meter	HRTT	0 ~ 999999H
Voltage Gauge	V	8-18VDC, battery voltage warning setttable
Gear indicator		N, R, 1, 2,...8 gears and off mode
Maintain reminder		9999km, 9999 hours or oFF
Bar-Fuel or Temperature Gauge	or	1-7 Bars, Adjustable 10Ω -990Ω, reserve mode, or not displayed

Power Input
Tachometer Sensor
Speed Sensor
Temperature Sensor
Speed input divider setup
Maximum speed input frequency
Wheel circumference setting
Dimensions

DC 8-18V
CDI or Ignition Coil Signal
Reed or hall Sensor
Thermo Sensor
1-199 Pulses
7K Hz
1mm-3999mm
Ø80*51.5mm


INSTALLATION & PARTS

Main Unit Installation:



RPM sensor mounting:

1. Connect either the grey wire to sense the RPM signal.
 - a.Signal strength from the ignition coil is dependent on coil type.
 - b.Coil 2-5 turns around spark plug lead, the more turns the stronger the signal. A weak signal will not show a reading on the screen whereas a very strong signal will have a reading which is too high or very jittery. If the reading is incorrect then try putting the 1MΩ resistor which is included in the box inline in the sensor wire.
- 2.The yellow wire can be wrapped around the spark plug lead.
3. If the sig nal is still unstable, please try to connect the grey wire to either the ECU rev counter output or to the primary side of the coil or to the pulse wire on an active spark plug cap.




- RPM-ECU/IGN (Grey Wire)
- RPM-PLUG (Yellow Wire)
- Either One
- H.T. Coil / CDI / ECU/ PLUG

SPEED SENSOR Mounting:

ACEWELL has several speed sensors; the unit may include one of them. If the model is intended to be connected to a gearbox electronic speed output to obtain the speed reading, no speed sensor will be included.


Reed Speed Sensor and Magnet:

1. This sensor is universal sensor for motorcycle, find a rotating part to install magnet (for example disk, sprocket or driveshaft) and a location to install the sensor where it can be aligned to the magnet.
2. Align the center of the magnet to either of the sensor marking lines or the side of the sensor. The magnet must not travel down the body of the sensor.
3. Installing the sensor parallel to the vibration direction creates optional anti-vibration effect.
4. Make sure the gap between the magnet and the sensor is within 8mm.



Hall Effective Speed Sensor and Magnet:

1. This is universal sensor for ATV or motorcyclefront or rear wheel installation or motorcycle front wheel installation. For some fitments an accessory speed sensor holder may need to be purchased.
2. Find a rotating part to install magnet (for example disk, sprocket or driveshaft) and a location to install the sensor where it can be aligned to the magnet
3. Align the center of the magnet to center of side face of the sensor.
4. Make sure the gap between the magnet and the sensor is within 5mm.



Specific Hall sensors:

Cable drive adaptors for most bikes originally fitted with cable driven speedometers or odometers are available. When using these cables it is necessary to divide the circumference setting by the number of rotations of the cable per rotation of the wheel.

Thermo Sensor and Sensor Tube:

1. The unit includes a water temperature sensor; you may have to purchase a suitable water pipe temperature sensor tube to install the sensor on some bikes.
2. Cut the water pipe, insert the temperature tube into the pipe and secure it by attached pipe clamps.
3. Screw the sensor into the tube.
4. If your vehicle is fitted with a thermostat that stops water flowing to the radiator when the engine is cold, you will not get a reading until the thermostat opens.
5. Custom sensors are available for carburetted bikes to replace the original sensor.

FUNCTIONS

RPM: Digital Tachometer

1. It displays digital tachometer up to 19,990rpm and displays 19,999rpm when tachometer is over 20,000rpm..
2. It has 2 wires to pick up RPM signal, the yellow wire is to connect to Plug, and white wire is for signal from ECU or Ignition coil.

Shift Warning RPM

1. The function enables you to set up a shift warning RPM.
2. The warning indicator turns on when RPM reaches setting value.
3. Each indicator turns off or stops flashing after you shift gear.

MAX RPM: Maximum Tachometer

Displays highest tachometer achieved since last Reset operation.

km/h or MPH: Speedometer

1. Displays speed mete r up to 399 km/h or 248 MPH.
2. The maximum frequency of software divider is 5K Hz.
3. With a small wheel size and large number of pulses per wheel revolution it may not be possible to display very high speeds.

MAX: Maximum Speed Meter

Displays highest speed achieved since last Reset operation

AVG: Average Speed Meter

It calculates average speed from last RESET. The AVG is calculated from TRIP1 be divided by RT.

TRIP 1or2: Trip Meter 1or2

TRIP function accumulates trip distance since last RESET as long as bike/ vehicle is moving.

TRIP 12: Trip Meter 3

1. TRIP-3 function appears and starts to accumulate trip distance automatically after low fuel warning LED is turned on.
2. TRIP-3 be reset to zero automatically when fuel is added to over the low fuel warning level.

ODO: Odometer

1. ODO accumulates total distance traveled.
2. ODO datemory and cannot be reset.

RT: Riding Timer

1. Calculates total running time since last RESET.
2. Counter automatically begins with movement.

TT: Total Riding Timer

1. Calculates total riding time from the beginning of the bike.
2. TT data is stored in memory, and cannot be reset.

HRTT: Hour Meter

1. Calculates total engine operation time since installation RESET.
2. Count automatically begins with engine starting.
3. HRTT data is stored in memory, and cannot be reset.

AM/PM: 12/24 hour Clock

It displays 12 or 24 hour current time.

°C/°F: Temperature Meter

1. It measures and displays from 0°C-180°C / 32°F-356°F.
2. It displays -L-°C or -L-°F when temperature is lower than 0°C(32°F) or disconnected temperature sensor, and displays -H- °C or –H-°F when temperature is over 180°C or 356°F..
3. The digits of temperature flash when the thermo sensor detects temperature higher than the maximum preset temperature.

MAX °C/°F: Maximum Temperature

Displays highest temperature achieved since last Reset operation.

V: Digital Voltage and Battery Warnings

1. It checks bike’s battery and charging systems health.
2. It has 3 modes to be set, b-on, b-oFF and b-HI, all 3 modes range is from 11.0V to 15.0V.
3. The “b-on” means battery warning on voltage, when the voltage falls below this the LED will flash.
4. The “b-off” means battery warning off voltage, b-off voltage must larger than b-on voltage.
5. The “b-HI” means battery high voltage, it comes on to warn that the batter has over charging.

: Gear Indicator

1. The gear indicator calculates gear by comparing speed and RPM then displays gear position.
2. User has to train the gear indicator before use it.

SCAN: Scan function

1. The 2nd row of LCD data will be changed automatically every preset number of seconds if the SCAN is selected. The scan period is from 1 to 20 seconds.
2. All functions will be manual operations when SCAN is switched off.

: Fuel Gauge or : Temperature Gauge

1. Has 5 bars to indicate how much fuel remains.
2. To use as a fuel gauge, the user enters the sender ‘empty’ resistance between 10 and 1000 ohms and the sender ‘full’ resistance between 10 and 990 ohms. The computer produces a linear scale of bars between these two resistances. When less than 10% fuel remains the gauge will flash and the warning LED if fitted will light.
3. To use as a reserve indicator, connect the reserve switch to the input and put into “rEs” mode. When the switch pulls the input to –ve the LED warning will light. On vehicles with temperature based sensors a 68 ohm 5w resistor needs to be connected between the input wire and 12v (switched).
4. If the bar-fuel gauge and warning lamp are is not required they can be switched off. Bar gauge will display for bar-temperature gauge instead of bar-fuel gauge as if the temperature meter set at on status.
5. Bar-fuel and temperature gauge will be total switched off if both setting are “off”.
 Trip or HRT: Maintenance Reminder
1. The maintenance reminder can set by either trip meter or hour meter, and an “Off” mode to switch it off.
2. The trip meter maintenance can be set up to 9999km.
3. The HRT maintenance reminder can be set up to 9999 hours.


BUTTON OPERATIONS

MODE Button (Right)

- Press the MODE button to move between all functions in sequence as “ → ” from one function screen to another when the speed sensor does not detect any signal input.
- Press the MODE button to move partial functions in loop sequence as “ → ”when speed sensor detects signal input.

RESET Button (Left)

Reset button cycles through functions in reverse order.



DATA RESETTNG AND PROGRAMMING MODES

- Press RESET button to reach the desired screen then press RESET button for 2 seconds to reset TRIP 2, MAX SPD, MAX RPM and MAX °C/°F data from stored values to zero individually. The maintain reminder data will be reset to the preset value rather than zero.
- The data of Trip 1, AVG & RT will all be reset at the same time when one of the 3 data functions is being reset.
- ODO, clock, HRTT and TT data cannot be reset.

Shift Warning RPM Operation

- Press RESET button 2 sec to reach the RPM screen; pull on the throttle until the desired shift warning RPM.
- When RPM overspeed, the backlight will flash to remind you shift gear.
- Press RESET button for 2 seconds at the RPM screen to re-adjust the shift warning RPM.

Gear Indicator training operations:

- If using a rear wheel or gearbox speed sensor, put bike on a rolling road or only securely mounted centre stand, if measuring front wheel speed the following can be done if the vehicle is moving.
- Change the LCD screen to display digital RPM.
- Press and hold MODE button for 2 seconds to go into the number of gears setting mode.
- Gear indicator flashes the default 0 gears.
- Press RESET button to select the number of gear, user can select 4-8 gears or “0” to disable the gear function.
- Press MODE button to confirm the number of gears and go to the number gear ratio setting mode.
- It displays and flashes “1”, shift bike’s gear to the 1st gear, run the engine to between 2000-4000RPM.
- Hold the speed and the RPM for about 5 seconds until the “-“flashing. The flashing “-“after the gear “1” means the 1st gear be set.
- Press MODE button to confirm the set and go to the 2nd gear setting.
- It displays and flashes “2”, shift bike’s gear to the 2nd gear, run the engine to between 2000-4000RPM.

- Hold the speed and the RPM for about 5 seconds until the “-“flashes. The flashing “-“after the gear “2” means the 2nd gear is set.
- Press MODE button to confirm the setting and go to next gear setting.
- Repeat the same operations as items 11-14 to set other gears until the last gear is set. Press MODE button to return to normal mode.
- At gear indicator setting mode, press and hold MODE button for 2 seconds to abort the setting if you need to re-set at any setting screen.

WHEEL CIRCUMFERENCE TABLE

- The details below have been calculated using following formula: Tire Diameter (inches) x 25.4(mm/inches) x 3.1416 = wheel circumference (in mm).
- Identify the tire size of your ATV/Motorcycle when you need to change different tire size and key in the corresponding number shown in the following

Tire outside diameter	Circumference number (mm)	Tire outside diameter	Circumference number (mm)	Tire outside diameter	Circumference number (mm)
15 inch	1197	19 inch	1516	23 inch	1835
16 inch	1277	20 inch	1596	24 inch	1915
17 inch	1357	21 inch	1676	25 inch	1995
18 inch	1436	22 inch	1756	26 inch	2075

- These values are approximate and will differ for different brands of tyre, we would always recommend that you measure the distance travelled per revolution of the wheel in mm and enter this into the computer.
- The computer calculates the wheel rotating length between 2 passes of the magnet; use this table to find the settings when you are using a reed sensor or an universal hall sensor with magnet to measure your speed.
- If you are using a cable drive speed sensor then enter the number of turns of the cable per turn of the wheel into the pulses screen.
- You can use more magnets, enter the number of magnets fitted into the pulses screen.
- If using a sprocket tooth counter speed sensor or internal pulse gearbox speed sensor enter the number of pulses per wheel revolution into the pulses screen.

Backlight, Clock, RPM, Wheel, Divider, Unit, Maintain, Thermometer, fuel meter and ODO SET UP

- Setup operations include backlight, 12/24hour clock, shift warning RPM, numbers of engine rotation per signal, SPD sensor, wheel circumference, speed pulses, units, maintenance, battery warning, temperature unit and warning, SCAN, fuel meter input resistance selection and odometer adjustment. These must be set up step by step. The computer will be automatically revert to normal mode if no button is pressed for 75 seconds at any setting screen.
- Press both MODE & RESET buttons to go into setting mode. In setting mode, each press of the RESET button increments the flashing digit by 1 or converts units. Press MODE button to confirm the digit setting and jump to next digit or next setting screen to be set. Press MODE button for 2 seconds at any setting screen to finish the setting and go to normal mode.
- It displays “5 & Led”, the flashing 5 can be set from 0 to 9, 0 means turn off the backlight, the more value of number the more brightness. Follow item 2 of button operation to finish the setting and jump to clock setting.
- It displays "12 or 24H and XX:XX:XX" symbols and AM/PM when you select 12H. Operate buttons as described in item 2 to finish clock setting and jump to shift RPM warning setting.
- It displays the default "RPM r06500", the digit “0” flashes. Follow the item 2 of button operation to finish the shift RPM warning setting and jump to engine specification setting.

- It displays "RPM SP 1r1P", the default value is 1r1P; there are 5 options: 1r1P, 1r2P, 1r4P, 2r1P, 3r1P,. “r” means the numbers of engine rotation, “P” means number of signals from engine. For example the value 2r1P means the engine rotates 2 turns to output one signal.
- Press RESET button to move in loop sequence from one to another value of the 5 values. Press MODE button to confirm the setting and go to speed sensor type screen.
- It displays SPD SE HALL or SPD SE rEEd, HALL type is for Acewell's unique 2 wires hall sensors only, rEEd type is for reed sensors, gear sensors and signals from ECU. A gear sensor has 3 wires and must be powered from the bike. Follow item 2 of button operation to confirm the sensor type and jump to wheel circumference setting screen.
- In "SPD cXXXX" display, "c" means "Circumference", following 4 default digits; flashing digit is digit to be set. Follow the item 2 of button operation to finish the wheel circumference setting and jump to signal divider setting.
- It displays "SPD P-001", the pulses screen, the number of pulses into the computer per turn of the wheel. Follow item 2 of button operation to finish the setting and jump to unit setting.
- It displays km/h or MPH, each press of RESET button converts unit; press MODE button to confirm unit setting and jump to maintain reminder setting.
- It displays and TRIP, HRT or oFF, TRIP is 1000km (621Miles) and RT is 100 hours by default. Follow the item 2 of button operation to finish the maintenance reminder setting and jump to voltage warning setting. The maintenance reminder function will be not be shown when “OFF” is selected.
- It displays “ b-on and a flashing numbers of voltage” to be set, “b-on” means battery warning on voltage – when the voltage falls below this the LED will flash, setting range from 11.0 to 15.0V. It displays “ b-off and a flashing numbers of voltage”, “ b-off” means battery warning off voltage, setting range from 11.0 to 15.0V to, but b-off voltage must larger than b-on voltage – when this voltage is exceeded the LED will go off. It displays “ b-HI and a flashing numbers of voltage” to be set, “ b-HI” means battery warning on voltage – when the voltage is exceeded the LED will come on, setting range from 11.0 to 15.0V“. Follow the item 2 of button operation to finish the voltage warning setting and jump to thermometer 1 setting.
- It displays " °C , °F or HI or oFF", each press of RESET button converts °C, °F, the temperature bars will disappear when you select oFF mode; press MODE button to confirm temperature setting and jump to temperature warning setting. In “HI” mode connecting the input wire to ground can flash the °C/°F icon.
- It displays " XXX" and the selected unit. Follow the item 2 of button operation to finish the temperature warning setting and go to scan setting.
- It displays SCAn on or oFF. If you select SCAn on, it means to display each function automatically. And SCAn oFF means turn off this function. Follow the item 2 of button operation to finish the SCAN setting and go to fuel sensor resistance setting.
- It displays “on, off or rES” and , it displays fuel tank and full bars as well flash XXXXr, it means full tank resistance setting, the setting range of “on” from 10r to 1000r. It displays fuel tank and one bar as well as flash XXXXr, it means empty fuel sensor resistance setting. Follow the item 2 to select a resistance same as your fuel sender odometer setting. The fuel meter bar will disappear if you select oFF mode and the thermometer setting set at “Off”; it will display “dotted line and ” in case the thermometer set “on”, bar-thermometer will be displayed instead of bar-fuel gauge at the status.In “rES” mode connecting the input wire to 0v can bring on the fuel symbol instantly.
- It displays “ODO & 00000X km”, the “X” is from odometer testing in factory, follow item 2 to set a desired odometer value and jump to clock setting or return to Normal Mode. This setting screen will disappear when the odometer is over 30km (18.6Miles) or your setting is over 30km.

MODE + RESET 2SEC

